# CBBAL / CBBF


BSA規格のBBシェル専用のカートリッジBBです。



#### SG Mighty テーパー

アクスルの規格です。BBとクランクは必ず SG Mighty テーパー 同士を組み合わせてください。 他のテーパー規格との互換性はありません。

#### BBの取り付け



① メインユニット (※逆ネジ) を、専用工具 TL-CBB を使用し て締め付けてください。

※ネジ部にはグリスを塗布してください。 ※逆ネジです。回す方向を間違えないよう注意してください。

#### 締め付けトルク: 50~70N.m (500~700kgf.cm)

② 左カップ(正ネジ)も同じトルク値で締め付けてください。 ※ネジ部にはグリスを塗布してください。



### BBの取り外し

- ① まずは 「クランク / チェーンホイールセットの取り外し〕 を行ってください。
- ② TL-CBBを使用し、メインユニットおよび左カップを取り外してください。

### 安全のために必ずお守り下さい。

誤った取り付け方法では、部品の折損や重大な事故につながる恐れがあります。

#### 点検・整備

- ●乗車前および乗車後には各所に緩みやガタが無いか点検を実施し、必要に応じてボルトの増し締めを行ってください。
- ●定期的に各部品のメンテナンスをしてください。

#### ▲ 警告

- ●適切な工具で適切な取り付けが行われなかった場合や自転車以外の用途に使用した場合、重大な事故につながる恐れがあります。
- ●マーキングや表面処理の変更、加工等の改造を行った場合、重大な事故につながる恐れがあります。
- 製品の取り付けや取り扱いに関して疑問のある方は販売店にご相談のうえ取り 付けを行ってください。正しく取り付け及び調整をされなかった場合は、破損 や重大な事故につながる恐れがあります。
- ●取り扱い説明書はよくお読みになった後、大切に保管してください。





# クランク / チェーンホイールセット(SG Mighty テーパー)

## クランク / チェーンホイールセットの取り付け

- ① まずは [BBの取り付け] を行ってください。
- ② BBアクスルのテーパー面 と クランクのテーパー穴とが正し く嵌っているか確認しながら、アクスルボルトを締め付けて ください。



アクスルボルトには種類がありますので、それぞれ適合する 工具(ボックスレンチや六角レンチ等)を使用してください。

#### 締め付けトルク: 40N.m (400kgf.cm)

③ もう一方のクランクも同様に取り付けてください。




※イラストの製品は一例です。


※CBBALのitalian仕様 (ITA規格用) も SG Mighty テーパーですので、組み合わせることができます。 フレームに合わせたBBをご使用ください。

## クランク / チェーンホイールセットの取り外し

- アクスルボルトを取り外してください。
- ② 専用工具 Extractor #202 (もしくは #203B) の先端のネジを、 クランクの奥までねじ込んでください。



③ 専用工具 Extractor #202 (もしくは #203B) の後方のネジを、 クランクが外れるまで締め付けてください。



④ もう一方のクランクも同様に取り外してください。





Extractor #203B

## CBBAL / CBBF


#### Cartridge BB for BSA frames.



#### SG Mighty taper

Axle standard. SG Mighty cranks should only be used on SG Mighty BB. SG Mighty taper is not interchangeable with other standards.

## BB installation



① Install the main unit (\*left-hand threads) to the BB shell and tighten it with the specialized tool TL-CBB.

\*Apply greace to the threads.

\*Left-hand threads, turn counterclockwise to tighten.

#### Tightening torque: 50~70N.m (500~700kgf.cm)

2 Install the left cup (right-hand threads) and tighten to the specified torque value as above.

\*Apply greace to the threads.



#### BB removal

- (1) Remove chainwheel set.
- 2 Remove the main unit and left cup with TL-CBB.

## Please fully obsarve the safety precautions as follow.

Incorrect installation may damage the parts and leads to serious accidents.

#### MAINTENANCE

- Before and after every ride, check all parts for play or looseness, and secure any loose parts and fasteners,
- Do regular routine checks on all parts.

#### **WARNING**

- Please use the appropriate tool for every installation. These parts are for use as specified for the bicycle indicated and shall not be used for other purposes. Inappropriate use may lead to serious accidents.
- Please do not alter these products, including changes in logos, surface treatment and so on, as it may cause serious accidents.
- If you have questions regarding installation and handling, please contact a professional. Incorrect installation and setting may damage the parts and lead to serious accidents.
- Please read the handling manual carefully and keep it at hand.

# SUGINO ENGINEERING CORPORATION


https://www.suginoltd.co.jp/us/

The specifications are subject to change without notice due to continua improvements.

# Crank / Chainwheel set (SG Mighty taper)

#### Crank / Chainwheel set installation

- 1) Install bottom bracket.
- 2 Make sure that the tapered end of axle fits correctly into tapered hole in the crank. And then, tighten the axle bolt.



\*Axle bolts are sold separately.

There are several types of axle bolts. Use appropriate tool (such as socket or hex wrench, etc.) to install the axle bolt.

#### Tightening torque: 40N.m (400kgf.cm)

3 Install the other crank on the other side of the axle in the same way.




\*The illustration is an example of SG Mighty cranks.


\*CBBAL Italian (for ITA frames) has SG Mighty tapered axle and can be used with SG Mighty cranks. So, please select an appropriate BB to your frame.


## Crank / Chainwheel set removal

- (1) Remove axle bolt.
- ② Insert the front threaded section of the specialized tool #202 (or #203B) into the crank dustcap threads and screw it all the way down.



(3) Insert the rear threaded section of the tool and screw it down until the crank comes off the axle.









Extractor #203B

4 Remove the other crank on the other side of the axle in the same way.