シマノ製クランク用の**フロントシングルチェーンリング**です。 シマノ12スピードおよび11スピードにて使用できます。 取り付ける前に、下記の適合クランクを確認してください。





※フロントダブルでの使用はできません。

※クランクおよび関連製品は別売りです。

適合クランク

ロードクランク

- FC-R9200 / R9100 [DURA-ACE]
- FC-R8100 / R8000 [ULTEGRA]
- FC-R7100 / R7000 / RS520 / RS510 [105]

グラベルクランク

• FC-RX820-1 / RX810-1 / RX610-1 / RX600-1 [GRX]

※型番はクランク裏面のペダル取り付け部周辺に表記されています。 必ずドライブ側(右クランク)を確認してください。 ※スギノ製クランクとの互換性はありません。

"PX"が付くパワーメータークラ ンクには使用できません。

▲▲ クランクの型番に "P" または

⚠ MTBクランクとの 互換性はありません。

関連製品

GRV4-SWNと併せて使用する製品(別売り)です。

704 for SHIMANO F-Single



ロードクランクの場合に用いる

804 for SHIMANO



グラベルクランクの場合に用いる チェーンリング固定ボルトです。 チェーンリング固定ボルトです。

STI Stopper Ver.2



フロント変速用のSTIレバー (デュアルコントロールレバー) のシフティングケーブルを固 定し、レバーの不要な動きを 抑止します。

取り付け

【図1】

表側

チェーンリング

取り付け面

裏側

- ① クランクからチェーンリングを取り外してくだ さい。
- ② 左記の [適合クランク] を確認してください。 クランクの種類によって GRV4-SWN の取り付 け方が異なるため、以降の手順が分岐します。

ロードクランク

αside


- ③ GRV4-SWN の **α** side を表にして、クランクの チェーンリング取り付け面の表側に配置してく ださい。- 【図1】 【図1-A】
- ④ GRV4-SWN の 凹部 がクランクアームと重なる 位置に来るようにしてください。-【図2-A】
- ⑤ 704 for SHIMANO F-Single (左記参照) を取り 付けてください。--【図3】

$\boldsymbol{\beta}$ side グラベルクランク

- ③ GRV4-SWN の **B** side を表にして、クランクの チェーンリング取り付け面の裏側に配置してく ださい。- 【図1】 【図1-B】
- ④ GRV4-SWN の 凹部 がクランクアームと重なる 位置に来るようにしてください。-【図2-B】
- ⑤ 804 for SHIMANO (左記参照) を取り付けてく ださい。- 【図3】

ロードクランク 【図1-A】 **Q** side

グラベルクランク 【図1-B】 Bside











安全のために必ずお守りください。

誤った取り扱いは、製品の破損や重大な事故に繋がる恐れがあります。

- ●乗車前および乗車後には各所に緩みやガタが無いか点検し、必要に応じてボルトの増し締めをしてください。
- ●定期的に各部品を点検してください。

洗浄

●製品を洗浄する際の洗剤やケミカルは、必ず中性表記のあるものを使用してください。酸性やアルカリ性のものを使用 した場合、製品の外観や機能を著しく損なう恐れがあります。洗車サービスを利用される場合にも必ずご確認ください。

▲警告

- ●適切な工具で適切な取り付けが行われなかった場合や自転車以外の用途に使用した場合、重大な事故に繋がる恐れがあ ります。
- ●マーキングや表面処理の変更、加工等の改造を行った場合、重大な事故に繋がる恐れがあります。
- 製品の取り付けや取り扱いに関して疑問のある方は販売店にご相談 ください。正しい取り付けおよび調整をされなかった場合は、破損 や重大な事故に繋がる恐れがあります。
- ●取り扱い説明書はよくお読みになった後、大切に保管してください。




製品改良のため仕様の一部を予告なく変更することがあります。 製品改良のため仕様の一部を予告なく変更することがありま MA-Chr GRV4-SWN (JP) 2025 0617

フロントシングル化に伴う注意事項

※フロントディレーラーは取り外してください。 また、STI Stopper Ver.2 (左記参照) を取り付けてください。

※GRV4-SWN は幅の異なる歯が交互に並んでいますので、歯と チェーンは 幅の広い方同士 および 幅の狭い方同士 を嵌め合わ せてください。- 【図4】

チェーンはコンポーネントに合わせて、シマノ製の12スピー ド用もしくは11スピード用のものを使用してください。





※ボルトにグリスを薄く塗布し、1~4の順に締め付けます。 締め付け後、全てのボルトに緩みがないか確認してくださ い。詳しくは、チェーンリング固定ボルトの取扱説明書を ご参照ください。

Front Single chainring for Shimano crank for Shimano 12 Speed & 11 Speed drivetrain. Before installation, check the crank compatibility.





- *Cannot be used for double-ring setup.
- *Crank and fixtures not included.

Crank compatibility

Road crank

- FC-R9200 / R9100 [DURA-ACE]
- FC-R8100 / R8000 [ULTEGRA]
- FC-R7100 / R7000 / RS520 / RS510 [105]

GRV4-SWN cannot be used with the power meter cranks which include "P" or "PX" in their model numbers.

Gravel crank

- FC-RX820-1 / RX810-1 / RX610-1 / RX600-1 [GRX]
- *Model information is shown above or surrounding the area on the pedal threads of the drive side crank.
- *Cannot be mounted on Sugino crank.

Cannot be mounted on MTB crank.

Fixtures

Required options for GRV4-SWN (sold separately).

704 for SHIMANO F-Single




704 Chainring fixing bolts for road crank

804 for SHIMANO



804 Chainring fixing bolts for gravel crank.

STI Stopper Ver.2



Install it on shifting cable to hold STI lever (dual control lever) in place.

Installation

[Fig.1]

- ① Remove original chainring from crank.
- 2 Check the [Crank compatibility] table. There are 2 different installation procedures depending on the crank types.

Road crank

⊘(side

- 3 Place GRV4-SWN on the outside of the crank ensuring that **\alpha** side mark is facing outwards. - [Fig.1] [Fig.1-A]
- 4 The recess of GRV4-SWN should be positioned under the crank arm. — [Fig.2-A]
- ⑤ Install 704 for SHIMANO F-Single (see fixture options), and then tighten each bolt. — [Fig.3]


Gravel crank


\mathcal{B} side

- 3 Place GRV4-SWN on the inside of the crank ensuring that β side mark is facing outwards. - [Fig.1] [Fig.1-B]
- 4 The recess of GRV4-SWN should be positioned under the crank arm. — [Fig.2-B]
- ⑤ Install 804 for SHIMANO (see fixture options), and then tighten each bolt. — [Fig.3]

Road crank [Fig.1-A] Chainring mounting surface Outside Inside **Q** side Countersunk


Gravel crank [Fia.1-B] Bside












[Fig.3] Tool 0 Torx wrench (Size: T30) Tightening torque 6.9N·m (70kgf·cm)

*Grease the bolts and tighten them down 1~4 in the numbered order. After installing all the bolts, make sure that they are secure. For details, see user's manual of the chainring fixing bolts.

Important points for converting to Front Single setup

- *Remove front derailleur and use STI-Stopper Ver.2 (see fixture options) on the front shifting cable.
- *GRV4-SWN has alternating narrow and wide teeth, fit narrow links on the narrow teeth and wide links on wide teeth. — [Fig.4]

Use Shimano 12 Speed or 11 Speed chain depending on your Shimano component.



Fully observe the followings for your safety.

Incorrect installation may damage the parts and leads to serious accidents.

- Before and after every ride, check all parts for play or looseness, and secure any loose parts and fasteners.
- Do regular routine checks on all parts.

CLEANING

• Be sure to use detergents or chemicals described as "neutral" to clean the products. Acidic and alkaline agents will harm finished surfaces and can cause malfunction to the products. When you receive a bike wash service, make sure that a neutral wash solution is use.

▲ WARNING

- Please use the appropriate tool for every installation. These parts are for use as specified for the bicycle indicated and shall not be used for other purposes. Inappropriate use may lead to serious accidents.
- Please do not alter these products, including changes in logos, surface treatment and so on, as it may cause serious accidents.
- If you have questions regarding installation and handling, please contact a professional. Incorrect installation and setting may damage the parts and lead to serious accidents.
- Please read the handling manual carefully and keep it at hand.

